


Module – 4 Optical Receivers

## Optical Detectors

- High Sensitivity at wavelength of interest
- High fidelity
- Fast Response speed/Sufficient BW
- Insensitive to temperature variations
- Compatible with dimensions of fiber
- Minimum addition of noise to the system
  - Shot noise
  - Receiver thermal noise
  - Beat noise
- PIN Photodiodes, Avalanche Photodiodes
- Direct detection / Coherent detection


## Electron-hole photogeneration

- Most modern photodetectors operate on the basis of the internal photoelectric effect the photoexcited electrons and holes remain within the material, increasing the electrical conductivity of the material
- Electron-hole photogeneration in a semiconductor
- Absorbed photons generate free electron- hole pairs
- Transport of the free electrons and holes upon an electric field results in a current



## Choice of photodiode materials


- A photodiode material should be chosen with a bandgap energy slightly less than the photon energy corresponding to the longest operating wavelength of the system.
- This gives a sufficiently high absorption coefficient to ensure a good response, and yet limits the number of thermally generated carriers in order to attain a low "dark current" (i.e. current generated with no incident light).
- Germanium photodiodes have relatively large dark currents due to their narrow bandgaps in comparison to other semiconductor materials.
- This is a major shortcoming with the use of germanium photodiodes, especially at shorter wavelengths (below 1.1  $\mu$ m)



## Junction photodiodes

- The semiconductor photodiode detector is a p-n junction structure that is based on the internal photoeffect.
- The photoresponse of a photodiode results from the photogeneration of electron-hole pairs through band-to-band optical absorption.
- The threshold photon energy of a semiconductor photodiode is the bandgap energy Eg of its active region.
- The photogenerated electrons and holes in the depletion layer are subjected to the local electric field within that layer. The electron/hole carriers drift in opposite directions. This transport process induces an electric current in the external circuit.

## Working principle of photodiodes




Structure and band diagram of photo-diode

# Why Photodiode detectors are usually operated in the strongly reverse-biased mode?

- A strong reverse bias creates a strong electric field in the junction that increases the drift velocity of the carriers, thereby reducing transit time
- A strong reverse bias increases the width of the depletion layer (W+D), thereby reducing
  the junction capacitance and improving the response time
- The increased width of the depletion layer leads to a larger photosensitive area, making it easier to collect more light.

## Absorption characteristics




• A GaAS photodiode has a bandgap energy of 1.43 eV at 300 K. Calculate the cut-off wavelength.

• A GaAS photodiode has a bandgap energy of 1.43 eV at 300 K. Calculate the cut-off wavelength.


$$\lambda_c = \frac{hc}{E_g} = 869nm$$

## Pin photodiode circuit



- p-i-n photodiode consists of an intrinsic region sandwiched between heavily doped p+ and n+ regions. The depletion layer is almost completely defined by the intrinsic region.
- In practice, the intrinsic region does not have to be truly intrinsic but only has to be highly resistive (lightly doped p or n region).


## Energy-band diagram (Why reverse bias?)



## Advantages of p-i-n photodiodes

- Increasing the width of the depletion layer which increases the area available for capturing light
- Increasing the width of the depletion layer reduces the junction capacitance and thereby the RC time constant.
- Reducing the ratio between the diffusion length and the drift length of the device results in a greater proportion of the generated current being carried by the faster drift process.

## Reverse-biased pin photodiode



$$P(w) = P_o [1 - \exp(-\alpha_s w)]$$

$$Ip = (q/hv) P_o [1 - \exp(-\alpha_s w)] (1-R_f)$$

$$R_f \rightarrow \text{reflectivity of detector surface}$$

## Quantum Efficiency & Responsivity

- η = number of electrons collected =  $I_p/q$ number of incident photons  $P_o/h_0$
- Responsivity  $\Re = I_p / P_o (A/W)$ =  $\eta q / hv = \eta q \lambda / hc$
- $\eta < 1$  for pin photodiode;  $\Re < 1$
- Upper cutoff  $\rightarrow \lambda_c = hc/E_g$

• In a 100ns pulse, 6\*10^6 photons at a wavelength 1300 nm absorbed by a InGaAs photodetector. On the average 3.9\*10^6 electron hole pairs are generated. Calculate the quantum efficiency

• In a 100ns pulse, 6\*10^6 photons at a wavelength 1300 nm absorbed by a InGaAs photodetector. On the average 3.9\*10^6 electron hole pairs are generated. Calculate the quantum efficiency


$$\eta = 0.65 = 65\%$$

• Photons of energy 1.53\*10^-19 J are incident on a photodiode which has a responsivity of 0.65 A/W. If the optical power level is 10  $\mu$ W, calculate the generated photocurrent.

• Photons of energy 1.53\*10^-19 J are incident on a photodiode which has a responsivity of 0.65 A/W. If the optical power level is 10  $\mu$ W, calculate the generated photocurrent.

$$I_p = RP_0 = 6.5 \mu A$$

## Photodiode Responsivities



• In the above figure, for the wavelength range 1100 nm <  $\lambda$  < 1600 nm, the quantum efficiency for InGaAS diode is about 60 %. Calculate the responsivity in this wavelength.

• In the above figure, for the wavelength range 1100 nm <  $\lambda$  < 1600 nm, the quantum efficiency for InGaAS diode is about 60 %. Calculate the responsivity in this wavelength.

$$R = \frac{\eta q}{h \nu} = 4.83 * 10^5 \lambda$$

$$R = 0.63 A/W$$

• When  $3*10^11$  photons each with a wavelength of  $0.85~\mu m$  are incident on a photodiode, on average  $1.2*10^11$  electrons are collected at the terminals of the diode. Determine the quantum efficiency and responsivity of the photodiode at  $0.85~\mu m$ .

• When  $3*10^11$  photons each with a wavelength of  $0.85~\mu m$  are incident on a photodiode, on average  $1.2*10^11$  electrons are collected at the terminals of the diode. Determine the quantum efficiency and responsivity of the photodiode at  $0.85~\mu m$ .

$$\eta = 0.4 = 40\%$$

$$R = \frac{\eta q}{h \nu} = 0.274 A/W$$